



Air Parcel in the Classroom Demonstration Setup



1. Tape two straws, end to end, and then repeat with two more straws. Then, tape all straws together so that they are perpendicular and make an "X."



2. Tape the top hole of the dry cleaner bag shut. Tape the ends of the straws to the bottom of the dry cleaner bag.



3. During the demonstration, have two students hold the bottom of the bag open as wide as possible. Set the blow-dryer to the hottest and highest settings. (If you have a very strong blow-dryer, you may want to set it to medium). Blow air into the bag, through the intersection of the straws, for about 3 minutes depending on the temperature of your classroom. Turn off the blow-dryer and then have students immediately let go of the bag.